

# BR512 Relay Terminal Box



## **FUNCTIONS:**

The **BR512** Relay Terminal Box enables easy on relay terminals or 5-track units.


Leaves the user hands free

## **OPERATING INSTRUCTIONS:**

1. Disconnect the relay to be tested.

2. Fit the BR512 interface between the vehicle part (1) and the relay (2).

3. Take the measurements (3) in the sockets.



## **CHARACTERISTICS:**

- Combined with the MX12 or with a multimeter, it enables rapid testing of:
  - power and control power supplies
  - power and control outputs

WARRANTY: 2 years Parts and Labour

- the following 5-track relays with 6.3 mm Fastons:
  - inverters, double switches, pre-heating, timed fan units (FIAT), indicators unit, buzzers, windscreen wiper tempo,...

Presentation In Blibox 245x180x55 mm - Net weight:400g

### www.exxotest.com

#### ANNECY ELECTRONIQUE

Parc Altaïs – 1, rue Callisto

**74650 CHAVANOD - FRANCE** Tel: 33/0 450 02 34 34 Fax: 33/0 450 68 58 93

Document n°: 43709 Issued 21/07/17